



COMMERCIAL GRADE

4'x10' Frame Kit


Assembly Instructions




TABLE OF CONTENTS - COMMERCIAL GRADE DOCK KIT

Dock Layout and Frame Assembly (Floating Only)4
Attaching Pipe Sleeves5
Attaching Hinges6
Attaching Floats7
Dock Layout and Frame Assembly (Roll-In or Stationary)8
Attaching Pipe Sleeves9
Attaching Clips10
How To Adjust Dock Height12
Wood Top Assembly13
Resin Dock Top Assembly14
Attaching Accessories15

COMMERCIAL GRADE DOCK KIT CONTENTS - PS 1005




(4) Outside Corner Brackets




(4) Inside Corner Brackets




(4) Corner Gussets



(4) Corner Connectors




(8) Plate Washers




(2) Pipe Sleeves


COMMERCIAL GRADE DOCK KIT HARDWARE CONTENTS




(52) 3/8" x 3" Carriage Bolts




(52) 3/8" Lock Washers




(52)
3/8" Nuts



(4) 3/8" Flange Nuts



(52) 3/8" Washers



(4) 3/8" x 1"
Hex Bolts


BILL OF MATERIALS



- Support Components:**
 (2) Foot Plates PS 1023
 (1) Pipe Safety Caps PS 1193
 (4) Connector Clips PS 1021
 (2) Dock Pipes

- Lumber:**
 (5) 2" x 6" x 10'
 (2) 2" x 6" x 8'
 (229) #8 x 2½" Deck Screws


Dock Top:
 *(11) 5/4" x 6" x 8' Decking



- Support Components:**
 (1) Dock Wheel Axle Kit PS 1198
 (2) Wheels PS 1334
 (1) Pipe Safety Caps PS 1193
 (4) Connector Clips PS 1021
 (3) Dock Pipes

- Lumber:**
 (5) 2" x 6" x 10'
 (2) 2" x 6" x 8'
 (229) #8 x 2½" Deck Screws

Dock Top:
 *(11) 5/4" x 6" x 8' Decking



- Support Components:**
 (3) Dock Floats PS 1155
 (1) CG Pipe Sleeve PS 1080
 (1) Auger PS 1100
 (8) Black Plates PS 1017
 (4) Joist Brackets PS 1015
 (1) Frame Hardware PS 1135
 (1) Float Hardware PS 1145
 (1) Pipe Safety Caps PS 1193
 (2) Hinge Kits PS 1070
 (1) Dock Pipes

- Lumber:**
 (5) 2" x 6" x 10'
 (5) 2" x 6" x 8'
 (229) #8 x 2½" Deck Screws

Dock Top:
 *(11) 5/4" x 6" x 8' Decking


NOTE: *(11) 5/4" x 6" x 8' Decking can be Substituted for Resin Dock Top

TOOLS REQUIRED

- Safety Glasses
- Measuring Tape
- Pencil
- Hammer
- Saw
- "C" Clamp
- Drill
- 1/8", 1/4" and 3/8" Drill Bits
- Carpenter's Square
- 3/8", 9/16" Socket and Ratchet

CUTTING GUIDE


2" x 6" x 10' – five (5) boards required




2" x 6" x 8' – two (2) boards required




5/4" x 6" x 8' – eleven (11) boards required when attaching a Wood Top



READ ALL INSTRUCTIONS THOROUGHLY BEFORE YOU BEGIN CONSTRUCTION. FLOATING DOCK PROJECT STARTS HERE.




DOCK LAYOUT EXAMPLES



KEY


- - Dock Pipe
- ⊕ - Pipe Sleeve Bumper
- ⊥ - Cleat
- ⌋ - Multi-Purpose Bumper



FRAME ASSEMBLY

Items for STEP 1:

- (3) 2" x 6" x 117" boards
- (4) 2" x 6" x 48" boards
- (24) #8 x 2½" galvanized deck screws



On a flat surface, lay out three 2" x 6" x 117" boards 21¾" apart. Measure and mark boards at dimensions shown.

Attach four 2" x 6" x 48" boards as shown. Make sure the assembly remains square while securing with #8 x 2½" galvanized deck screws.

Items for **STEP 2:**


- | | |
|-----------------------------|--|
| (4) Outside Corner Brackets | (64) $\frac{3}{8}$ " x 3" Carriage Bolts |
| (4) Inside Corner Brackets | (64) $\frac{3}{8}$ " Flat Washers |
| (4) Corner Gussets | (64) $\frac{3}{8}$ " Lock Washers |
| (8) Corner Connectors | (64) $\frac{3}{8}$ " Nuts |
| (16) Plate Washers | |

Position outside corner bracket centered top to bottom. Use the bracket as a drill guide and drill $\frac{3}{8}$ " holes completely through the boards.

Repeat for all the brackets.


**Refer to page 4 for layout of hinges and pipe sleeves which need to be installed at this time.
See pages 5 & 6 for installation instructions.**

Attach brackets with $\frac{3}{8}$ " x 3" carriage bolts, $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and $\frac{3}{8}$ " nuts as shown.



COMMERCIAL GRADE PIPE SLEEVE PS 1080 (Floating Only)

Attach the pipe sleeve to the Framing Kits as shown when assembling the corner hardware.



Refer to your specific project for locations.

ATTACHING HINGES



STRAIGHT CONNECTION

Attach the Hinges to the Frame Kits as you assemble the corner hardware.

Position a long hinge (with notch) in each corner of one 4' side of the dock section as shown.

Position short hinges (no notch) in each corner of one 4' side of the next dock section to be attached

Refer to your specific project for locations.



Note: The short hinge (no notch) half should be attached to the end of dock sections furthest from shore.

90° CONNECTION

Attach the Hinges to the Frame Kits as you assemble the corner hardware.


Position a long hinge (with notch) in corner of one 10' side of the dock section.

Position second long hinge (with notch) so that the center distance between the mounting holes is $40\frac{7}{8}$ " as shown.

Use the long hinge (with notch) as a drill guide and drill $\frac{3}{8}$ " holes completely through the board.

Use a plate washer for reinforcement on both sides of the frame as shown.

Refer to your specific project for locations.




Items for STEP 3:

- (2) 2" x 6" x 117" boards
- (16) #8 x 2½" galvanized deck screws

Position 2" x 6" x 117" boards at dimensions shown.

Secure with #8 x 2½" galvanized deck screws as shown.




**Turn to page 13 if you are attaching a wood top.
Turn to page 14 if you are attaching the Resin Dock Top (PS 1320).**

ATTACHING FLOATS

Items for this STEP:



- (12) ¾" x 2" lag screws
- (12) ¾" flat washers

Position floats as shown.



Use the float as a drill guide and drill ¼" holes 2" deep on the sides only.


Secure with ¾" x 2" lag screws with ¾" washers as shown.



Do not attach a float to the gang-plank section closest to shore as shown.


The end without the float must rest firmly on land.

Refer to your specific project for locations.




COMMERCIAL GRADE AUGER PS 1100

(Floating Only)




Drill one ¾" hole in pipe 1½" up from the end. Insert Auger into the pipe, align holes and finish drilling opposite side. Secure with the nut and bolt provided.

READ ALL INSTRUCTIONS THOROUGHLY BEFORE YOU BEGIN CONSTRUCTION. STATIONARY OR ROLL-IN DOCK PROJECT STARTS HERE.




DOCK LAYOUT EXAMPLES



KEY


- - Dock Pipe
- Pipe Sleeve Bumper
- ⊓ - Cleat
- ▭ - Multi-Purpose Bumper



FRAME ASSEMBLY

Items for STEP 1:

- (3) 2" x 6" x 117" boards
- (4) 2" x 6" x 48" boards
- (24) #8 x 2½" galvanized deck screws



On a flat surface, lay out three 2" x 6" x 117" boards 21¾" apart. Measure and mark boards at dimensions shown.

Attach four 2" x 6" x 48" boards as shown. Make sure the assembly remains square while securing with #8 x 2½" galvanized deck screws.

Items for **STEP 2:**

- | | |
|-----------------------------|--|
| (4) Outside Corner Brackets | (48) $\frac{3}{8}$ " x 3" Carriage Bolts |
| (4) Inside Corner Brackets | (48) $\frac{3}{8}$ " Flat Washers |
| (4) Corner Gussets | (48) $\frac{3}{8}$ " Lock Washers |
| (4) Corner Connectors | (48) $\frac{3}{8}$ " Nuts |
| (8) Plate Washers | |


Position outside corner bracket centered top to bottom. Use the bracket as a drill guide and drill $\frac{3}{8}$ " holes completely through the boards.

Repeat for all the brackets.

Refer to page 8 for layout of Pipe Sleeves and Clips which need to be installed at this time.




See pages 9-11 for installation instructions



Attach brackets and any pipe sleeves and clips with $\frac{3}{8}$ " x 3" carriage bolts, $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and $\frac{3}{8}$ " nuts as shown.



ATTACHING PIPE SLEEVES



Attach the pipe sleeves to the frame as you assemble the corner hardware as shown. Secure with $\frac{3}{8}$ " x 3" carriage bolts, $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and $\frac{3}{8}$ " nuts.





NOTE:


*The pipe sleeves should be attached to the 10' side of the dock for a straight connection.
The pipe sleeves should be attached to the 4' side of the dock for a right-angle connection.*



ATTACHING CLIPS

STRAIGHT CONNECTION

Refer to your specific project for locations.



NOTE:

The end of the dock section with pipe sleeves will always have the clips with center tab pointing up.

Attach the clips to the frame as you assemble the corner hardware.

Position a clip with center tab pointing up in each corner of one 4' side of the dock section as shown.

Position clips with center tab pointing down in each corner of one 4' side of the next dock section to be attached.


90° CONNECTION

Refer to your specific project for locations.

Attach the clips to the frame as you assemble the corner hardware.

Position a clip with center tab pointing up in corner of one 10' side of the dock section as shown.

Position second clip with center tab pointing up so that the center distance between the outside mounting holes is $40\frac{7}{8}$ " as shown.



Use the clip as a drill guide and drill $\frac{3}{8}$ " holes completely through the board.


Attach with $\frac{3}{8}$ " x 3" lag screws, $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and nuts.

Items for **STEP 3:**

- (2) 2" x 6" x 117" boards
- (16) #8 x 2½" galvanized deck screws

Position 2" x 6" x 117" boards at dimensions shown.


Secure with #8 x 2½" galvanized deck screws as shown.



**Turn to page 13 if you are attaching a Wood Top.
Turn to page 14 if you are attaching the Resin Dock Top (PS 1320).**

HOW TO ADJUST DOCK HEIGHT

Stationary



Roll-In





Figure 1




Figure 2



Position two $\frac{3}{8}$ " flange nuts into pipe sleeve as shown. (Figure 1)

Insert dock pipe into pipe sleeves at desired height.

Tighten pipe with $\frac{3}{8}$ " x 1" hex bolt and $\frac{3}{8}$ " flange nut as shown. (Figure 2)

ROLL-IN OPTION

Roll-In



SHOWN WITH
WOOD TOP



Purchase Separately:

- (2) PS 1198 Dock Wheel Axle Kit
- (2) PS 1334 Dock Wheels
- (3) Dock Pipe

Follow the complete assembly instructions included in your PS 1198 Dock Wheel Axle Kit.

STATIONARY OPTION

Stationary




SHOWN WITH
WOOD TOP

Purchase Separately:


- (2) PS 1023 Commercial Grade Foot Plate
- (2) Dock Pipe

Attach foot plate to dock pipe as shown.




WOOD TOP ASSEMBLY


Stationary



Roll-In



Floating




Items for this step:

- (3) 5/4" x 6" x 48" boards
- (27) #8 x 2 1/2" galvanized deck screws

Position one board flush at each end of the frame and one directly in the middle as shown.

Secure each board with nine #8 x 2 1/2" galvanized deck screws.




SHOWN WITH
FLOATING FRAME

Items for this step:

- (18) 5/4" x 6" x 48" boards
- (162) #8 x 2 1/2" galvanized deck screws

Position boards equally spaced between existing boards.

Secure each board with nine #8 x 2 1/2" galvanized deck screws.




SHOWN WITH
FLOATING FRAME




**Turn to page 7 if you are building a Floating Dock.
Turn to page 12 if you are building a Roll In or Stationary Dock.**

RESIN DOCK TOP ASSEMBLY


Stationary



Roll-In




Floating




Items for this step: (included in PS 1320 RESIN DOCK TOP)

- (4) dock top corners
- (6) dock top sides
- (16) $\frac{3}{8}$ " x $1\frac{1}{4}$ " hex bolts
- (32) $\frac{3}{8}$ " flat washers
- (16) $\frac{3}{8}$ " lock nuts



Assemble the tops into two halves as shown. Install $\frac{3}{8}$ " x $1\frac{1}{4}$ " hex bolts, $\frac{3}{8}$ " washers and $\frac{3}{8}$ " lock nuts at each starred location. **Finger tighten only.**





Note: If bolts are completely tightened, attaching the top to the frame will be difficult.

Items for this step:

(included in PS 1320 Resin Dock Top)

- (48) $\frac{1}{4}$ " x $1\frac{1}{2}$ " self-drilling hex screws
- (48) $\frac{1}{4}$ " fender washers



Position the two halves together and centered on the frame as shown.

Beginning with the exterior holes, secure with $\frac{1}{4}$ " x $1\frac{1}{2}$ " self-drilling hex screws and fender washers. **Do not overtighten.**




**Turn to page 7 if you are building a Floating Dock.
Turn to page 12 if you are building a Roll In or Stationary Dock.**


ATTACHING ACCESSORIES

(PURCHASE SEPARATELY)

Stationary



Roll-In




Floating



PIPE SLEEVE BUMPER

PS 1188 (hardware provided)

Install two $\frac{3}{8}$ " nuts and $\frac{3}{8}$ " flat washers on each U-bolt as shown. Attach the pipe sleeve bumper to the U-bolts around the pipe sleeve. Secure with $\frac{3}{8}$ " flat washers, $\frac{3}{8}$ " lock washers and $\frac{3}{8}$ " nuts.




Refer to your specific project for locations.

RESIN DOCK CLEAT 8" PS 1191

(hardware not provided)

Position cleat in desired position. Use cleat as a drill guide and drill two $\frac{1}{8}$ " holes. Secure with $\frac{1}{4}$ " x 4" lag screws and $\frac{3}{8}$ " flat washers.

Refer to your specific project for locations.





MULTI-PURPOSE BUMPER PS 1352

(hardware not provided)

Position Bumper in desired location. Use Bumper as a drill guide and drill $\frac{1}{4}$ " holes 2" deep. Secure with $\frac{3}{8}$ " x 2" lag screws with $\frac{3}{8}$ " washers as shown.

Refer to your specific project for locations.




PREMIUM DOCK CLEAT PS 1354

(hardware not provided)

Position Cleat in desired location. Use Cleat as a drill guide and drill $\frac{1}{4}$ " holes 2" deep. Secure with $\frac{3}{8}$ " x 2" lag screws with $\frac{3}{8}$ " washers as shown.

Refer to your specific project for locations.



Thank You for choosing PlayStar. Because it is our intention to make this a positive family experience, we have taken great care in preparing this product. Should you have any questions or if we can assist you in any way, please call our friendly Customer Service Department for immediate action.

Do not return to the store.
Please call us Toll Free at 1-888-PLAYSTAR
(752-9782)

Monday through Friday, 8:00 A.M. to 5:00 P.M. C.S.T.

Ask for Customer Service.

We Will Gladly Help!



PlayStar, Incorporated, Janesville, WI 53547

© 2010, PlayStar, Inc. Reproduction of this document in part or whole is prohibited without the permission of PlayStar, Inc.

Patents Pending or Protected by one or more of the following United States or Foreign Patents: US 6,098,564; US 6,145,463; US 7,153,064; CA 2,270,012; CA 2,261,438